




SET OR CHANGE TIME AND DATE



With the system off, press the Menu button and the On/Off button simultaneously.



The settings menu will appear.



Press the Menu button once to increase number, hold the Menu button to move on.



Hold the Menu button on the last number to finish. The device will start.